

SymStride

Michael, Ido, Yibo

Motivations and Objectives

- **Motivation**


- Video based running analysis (like Ochy) needs cameras, lighting, and privacy trade-offs.
- IMUs are low-cost, portable, and enable motion tracking

- **Objectives**

- Use pre-existing IMU data + ML models to reconstruct human motion
- Derive key kinematic metrics from pose (e.g. hip, knee, ankle, elbow angles)
- Recreate key results from Ochy **without** video capture

- **Impact**

- **Coach level analysis of running form** for both novice runner and for running enthusiasts **without the need for a flow your day-to-day running**



Technical Approach and Novelty

- **Current Approaches:**


- Optical motion capture:
 - Very accurate but extremely expensive, also requires controlled indoor lab environments
- Smartphone apps (e.g. Ochy):
 - Uses computer vision from video to estimate 2D or pseudo-3D poses
 - Limited by camera angle, lighting, occlusion, and **need to set up phone as separate from run**

- **Our Approach:**


- Use IMU configurations placed on predetermined body segments (pelvis, legs, arms, head)
- Feed IMU data to ML model to reconstruct full 3D pose
- From reconstructed pose, compute joint angles (hip, knee, ankle, elbow)
- Use pose to create running metrics outline by current competitors (i.e. Ochy)

- **Novelty:**

- IMU-only workflow, completely removes the need for cameras or optical markers



Methods



- **Algorithm:**


- Collect data offline asynchronously
- Run the IMU data through pre-existing, fine-tuned ML models to extract the 3D poses
 - DIP
 - MobilePoser
- Relative-rotation computation for angles
 - Compute relative body part angles to measure difference between body sides and running best practices (e.g. acute angle for leg while running)

- **Data:**

- AMASS Dataset (Motion Capture Sequences of humans)
 - DIP-IMU
 - TotalCapture
 - CMU


- **Platform:**

- Python backend (NumPy, PyTorch, aitviewer, local inferencing)
- Visualization via website
- SensorLogger (IMU access iPhone, AirPods, Apple watch)



Evaluation and Metrics

- **Goal:** Matching our IMU derived metrics to vision derived metrics in Ochy
- **Approach:**
 - Run the same motion through both systems (Ochy and our IMU pipeline)
 - Compare the resulting hip, knee, ankle, and elbow angles
 - Compare the higher level insights (heel drive, gait cycle, etc.)
- **Metrics** (our derived metrics vs. Ochy's):
 - Mean absolute error per joint angle
 - Standard deviation of error (consistency of our model's estimates across movements)
 - Is the difference significant?
- **Success Criteria:**
 - Small differences and similar angle patterns between IMU calculated joint angles and Ochy's metrics → Similar insights into running form




Current Status and Next Steps

- **Status:**

- Gotten datasets used for model training
- Replicated IMU → human mesh pipeline with real IMU data for a few pre-existing models
- Fine-tune using running data
- DIP-IMU model produces results with varying accuracy

- **Next Steps:**

- Explore the calculations for angles and more advanced running form analysis
- Validate the models with real IMU-Video data
- Exploring the different combinations of IMU devices we can use
- Fine tuning model to work with running and reduce jitter




References

V. Xu, C. Gao, H. Hoffmann, and K. Ahuja, “MobilePoser: Real-Time Full-Body Pose Estimation and 3D Human Translation from IMUs in Mobile Consumer Devices,” Human-Computer Interaction, pp. 1–11, Oct. 2024, doi: 10.1145/3654777.3676461.

Y. Huang, M. Kaufmann, E. Aksan, M. J. Black, O. Hilliges, and G. Pons-Moll, “Deep Inertial Poser: Learning to Reconstruct Human Pose from Sparse Inertial Measurements in Real Time,” arXiv.org, Oct. 10, 2018. <https://arxiv.org/abs/1810.04703>

Thank you!





Run Analysis Overview

Duration: 25:30 Steps: 3420

Overall Symmetry

EXCELLENT

100%



Asymmetry Score

0.8%

Lower is better. Measures overall form deviation.

Knee Angle Symmetry

99%

Left: 165.5° | Right: 164.6°

Hip Angle Symmetry

100%

Left: 170.4° | Right: 169.6°

Ankle Angle Symmetry

100%

Left: 110.2° | Right: 109.7°

Stride Length Symmetry

86.92480687884182%

Consistency in step length between legs.

Foot Landing

76%

Left: heel | Right: heel

Back Position

5.7°

Forward lean: 5.7° (Good)

Front Knee at Landing

96%

Left: 163.7° | Right: 157.0°

Arms Position

94%

Angle symmetry: 94% | Swing: 88%

Recommendations



Focus on maintaining equal knee flexion between both legs during the stance phase



Work on hip alignment - ensure both hips remain level throughout the running cycle

Joint Angle Analysis

Real-time monitoring of joint angles to detect asymmetries in running form

Knee Angles

LEFT VS RIGHT

165.6° **164.6°**

Symmetry: 99%

Hip Angles

LEFT VS RIGHT

170.4° **169.7°**

Symmetry: 100%


Ankle Angles

LEFT VS RIGHT

110.3° **109.7°**

Symmetry: 99%

Joint Angle Over Time



Overall Asymmetry Score

0.8%

LOW ASYMMETRY

Lower scores indicate better symmetry. Aim for < 2% asymmetry.

Symmetry Breakdown

Knee LOW

Asymmetry: 1.0° Symmetry: 99%


Hip LOW

Asymmetry: 0.7° Symmetry: 100%

Ankle LOW

Asymmetry: 0.6° Symmetry: 99%

Angle Asymmetry by Joint



Symmetry Radar Chart



Key Insights



Knee Angle Asymmetry Detected



Hip Alignment is Good



Ankle Symmetry Improving

Form Analysis

Detailed analysis of running form including foot landing, posture, and body positioning

Foot Landing

LEFT vs RIGHT
Heel vs **Heel**

Symmetry: 76%



Aim for midfoot or forefoot landing for better shock absorption

Back Position

5.7°

Forward Lean

GOOD

Symmetry: 85%



Maintain slight forward lean (5-8°) for optimal running efficiency

Front Knee Angle at Landing

LEFT vs RIGHT
163.7° vs **157.0°**

Symmetry: 96%



Optimal: 160-165° for efficient shock absorption

Back Knee Angle at Landing

LEFT vs RIGHT
26.3° vs **32.0°**

Symmetry: 80%



Optimal: 25-35° for proper leg recovery

Arms Position

LEFT vs RIGHT
89.3° vs **84.4°**

Angle Symmetry: 94%



Swing Symmetry: 88%



Keep arms at 85-90° angle, avoid crossing midline

Head Position

TILT vs FORWARD POSITION
+1.5° vs **3.2 cm**

Symmetry: 90%



Keep head neutral, eyes looking 10-20m ahead